

AquaTeak Care and Maintenance

Care and Maintenance Guide

1. Sweep or hose the deck to remove loose dirt, sand and debris.
2. General maintenance: Dilute Treadmaster cleaner with warm water at a ration 1:100. Scrub the deck in the direction of the grain with a stiff bristled brush.

Stubborn Stains: Dilute Treadmaster cleaner with warm water at a ration 1:10. Scrub the deck in the direction of the grain with a stiff bristled brush and leave for 2-3 minutes. DO NOT ALLOW TO DRY. Always test in an inconspicuous area when mixing at higher concentrations

3. Rinse thoroughly with clean water
4. Allow to dry naturally
5. Aquateak can be cleaned with a pressure washer. Avoid excessively aggressive pressure washing.

Important things to avoid:

- ✗ Bleach based cleaners
- ✗ Abrasive cleaners and scouring powders
- ✗ Excessively aggressive pressure washing

Aquateak is sanded during manufacture. As a last resort to remove stubborn stains. Lightly hand sand along the grain using 120 grit sandpaper taking care ensure the surface is evenly sanded.